



# Easy Cow Lifter



Lift any cow in your herd easily in a few minutes. The Easy Cow Lifter is made of heavy-duty PVC with reinforced polyester webbing straps. Lifter avoids pressure points on the cow, and there are no leg holes to struggle with, making this a simple one-person operation. The crossed straps and support pad, placed behind the udder and under the tail, fully support the cow so she can remain in the sling as long as required and, most importantly, stay comfortable. Easy Cow Lifter attaches to any lifting device through zinc plated C-hooks.

**10023** Easy Cow Lifter, comes complete with carry bag, zinc plated C-hooks and gambrels to attach to your lifting device, loader arms or hay forks.


**EASILY FITTED** - no tangles

**LIGHT TO CARRY** - no long pipes

**NO RESTRICTIONS** - no pressure points

**FULLY SUPPORTIVE** - for transportation

**INSTANTLY ADJUSTABLE** - fits any size cow



#### INSTRUCTIONS:

1. Remove front end loader bucket and attach the C-hooks to the bucket pivot holes of the front end loader frame or hay forks.
2. Lay the sling out adjacent to the cow, ensuring the brisket support is to the front and the webbing side upwards.
3. Spread the front and rear straps out and away from the sling. Roll the cow onto her stomach in the center of the PVC section. If you cannot roll the cow over, you can work the sling under the cow by pulling on the lifting triangles sewn at the end of the PVC section.
4. Connect the four triangles at the end of the yellow PVC section to the gambrel hooks.
5. Position the rear straps between the udder and the legs and slide the rear support pad halfway between the udder and tail and connect to the gambrel hooks.
6. Position the front straps between the front legs and **CROSS OVER** above the neck and connect to the gambrel hooks.
7. Lower the lifting device and connect the C-hooks to the gambrels.
8. Tighten the front and rear straps before you make the initial lift.
9. Now lift the cow and ensure that the sling is as far forward as possible and that no pressure is on the udder.
10. Adjust the front and rear strap lengths to achieve even support of the cow between these straps, the brisket support, and the main sling area.
11. The cow can now be lifted entirely off the ground and transported safely into a barn.
12. Used for short periods, you encourage blood circulation and feeding, then by reducing the height lifted over a period, the cow becomes fully mobile again.
13. Pivot bar available by request for use with Easy Cow Lifter when used in wintering.

Ins.10023-EasyCowLift.2020.12



The Coburn Company, Inc. • PO Box 147 Whitewater, WI 53190 USA  
 800 776 7042 • 262 473 2822 • [coburn.com](http://coburn.com) • [info@coburn.com](mailto:info@coburn.com)